



VBG Spare parts / VBG 590V

Pos	Part No	Part Name	Specification	Kit
1	09-065400	Nut cover	incl. split pin for VBG 750V/795V/795V-2/575V/590V/575V-2	
2	18-004900	Castellated nut	for VBG 750V/795V/795VR/7310D/575V/590V/ 590VR/575V-2/590VR-2	
3	18-054900	Bearing plate	inner for VBG 750V/795V/795V- 2/7310D/7310D-2/575V/590V/575V-2	
4	05-063400	Screw kit	for drawbeam sleeve for VBG 750V/795V/795VR/575V/590V/590VR /575V-2	
5	09-066200	Rubber bearing kit	incl. 09-065400	
6	09-067300	Drawbeam sleeve	for VBG 795V/795V-2/590V incl. pos. 1, 4 and 5	
7	18-054700	Bearing plate	outer for VBG 750V/795V/795V- 2/575V/590V/575V-2	
8	09-121300	Bushing kit	for VBG 575V/590V/590VR	
9	09-123600	Screw kit	for mechanism cover	
10	09-182700	Handle L		
11a	09-126300	Signal pin kit		
11b	09-181300	Indicator & locking device kit		
12	09-123100	Mechanism cover		
13	09-120800	Screw kit	for mechanism for VBG 575V/590V/590VR/575V-2	
14a	09-177500	Grease plug	10 pcs.	
14b	09-127000	Grease plug	3 pcs.	
15	09-120900	Cover kit	for VBG 575V/590V/590VR	
16	09-121000	Mechanism	for VBG 575V/590V/590VR incl. 09- 121300, 09-120800, 18-061400, 09- 121100	
17	09-127100	Plastic plug	for position sensor	
18	18-061400	Torsion spring	for guiding funnel for VBG 575V/590V/590VR	
19a	09-124100	Guiding funnel	for VBG 575V/590V/590VR	
19b	09-061073	Guiding funnel	for VBG 575V/590V version 2.0	
20	09-121200	Wear plate holder	for VBG 575V/590V/590VR	
21	09-121100	Wear plate kit	for VBG 575V/590V/590VR incl. 09- 121200	
22	09-123700	Cap	for handle	
23	09-123300	Handle	A	
24	09-126400	Sleeve kit 67 mm	for moving handle from left to right side	
25	09-126500	Closing spring kit		
26	09-177600	Sealing kit	for cover	